



Aluminum Landscape Edging

INSTALLATION INSTRUCTIONS

Required tools: Spade, Hammer, Hacksaw (Edger/trencher - optional)

- 1. Lay out area to be edged.**
A garden hose or string works best.
- 2. Spade a vertical wedge in ground**
approximately 4" deep and 3"- 4" wide.
- 3. Begin placing edging in trench** with the top 1/2" (12.5cm) above what will become the compacted finish grade.
- 4. Slide ends of edging strips together** to connect pieces. Installer can connect the adjacent section of edging prior to or after the sections are placed in the trench. A minimum of 2 inches (50.8mm) of overlap is recommended, with a preferred 4 inch overlap.
- 5. Cut edging section to the desired length** at the end of the bed area.
- 6. Drive spikes through holes in edging at a 45 degree angle.** Start with the beginning piece of edging.
- 7. Stake and backfill edging**
continuously to ensure straight lines, compacting both sides to ensure the finish grade is approximately 1/2" below top of edging.

If you have any questions or comments on the installation or performance of this edging, please call Sure-loc Aluminum Edging at 1-800-787-3562.

EACH BOX INCLUDES:

4 - 6ft Sections aluminum edging (24 linear feet total) **12 - Spikes**

MADE IN THE U.S.A.

